


ROBY


23-May-2017












ROBY 2.6 & ROBY 3.5 have the same base plate mounted.

DIMENSIONS




MOUNTING INSTRUCTION

- 1) Put the ROBY cover on top of the fixture before mounting the fixture to the ceiling.
- 2 Attach the ceiling base to the ceiling with screws.

POWER CONNECTION

3 Interior connection: STANDARD version



The light source of the integrated LED is not replaceable; When the light source reaches its end of life the whole luminaire should be replaced.



Caution, risk of electric shock

