



S I M E S


MEGALINK PALETTO
MEGALINK BOLLARD



5




6




MEGALINK


7



8





12



PER LE ISTRUZIONI DI CABLAGGIO, INDICAZIONI D'USO E LIMITAZIONI FARE RIFERIMENTO ALLE RELATIVE ISTRUZIONI DI MONTAGGIO INCLUSE CON IL PRODOTTO DELLA SERIE LINK ACQUISTATO.

FOR THE WIRING, INDICATION AND LIMITATION ABOUT THE PRODUCT PLEASE REFER TO THE MOUNTING INSTRUCTION ANNEXED WITH THE LINK FAMILY PRODUCTS.



- I Utilizzare solo cavi di alimentazione in doppia guaina. Non entrare con fili singoli.
- GB Use only supply cables with double case. Do not enter with single cables.
- D Brauchen Sie nur die Speisekabel mit doppeltem Mantel. Do not enter with single cables.
- F Utiliser seulement cables d'alimentation avec double gaine. Do not enter with single cables.
- E Use only supply cables with double case. Do not enter with single cables.
- SE Use only supply cables with double case. Do not enter with single cables.
- NL Use only supply cables with double case. Do not enter with single cables.
- RU Use only supply cables with double case. Do not enter with single cables.
- FI Use only supply cables with double case. Do not enter with single cables.
- P Use only supply cables with double case. Do not enter with single cables.



SIMES S.p.A. VIA G. PASTORE 2/4 - 25040 CORTE FRANCA (BRESCIA) - ITALY
TEL. +39 0309860430 - FAX +39 0309860439
E-mail: simes@simes.it - <http://www.simes.it>