



17-Dec.-2016










base plate dimensions







DIMENSIONS




MOUNTING INSTRUCTION

Remove the screws of the top part, put the cables through the opening and mount the base on the ceiling.

2 POWER CONNECTION

Connect wiring to the power supply (for LED) or to terminal block (for PAR16) interior connection: STANDARD version



FOR LED

Attach the LED housing on the base by two allen screws.

Attach the HEXO cover to the LED housing by screwing the locking ring

FOR PAR16

Attach the HEXO cover to the base by screwing the locking ring

5 OPTIONAL inner cover

put the inner cover in the outer cover by screwing. with inner cover: max. 10W when using the inner cover you don't need the locking ring.

