# ARMANI / CASA



**PAMELA** 

Floor lamp

## ARMANI/CASA

#### **PAMELA**

#### **DESCRIPTION**

Pamela is a lamp available both in table and floor version. The distinctive feature of this lamp is the thin metal stem, sculpted to resemble a bamboo cane and connected to a circular base developed on more levels. On the table version, the switch/dimmer - featuring the GA logo and a touch technology - is located on the base; on the floor version, it can be found on the stem. Available with truncated cone shade in fabric (white, red or forest green) or in a special micro-perforated elm wood. The intricated design of the latter is inspired by wicker patterns, and creates a special seethrough effect with geometrical reflections of the light. The wood of this shade is coupled with a inner layer of PVC and features decorative metal rings on the borders, as well as two diffuser discs (above and below the light source); the fabric shade, instead, features a upper disc only.

Like all Armani/Casa lamps, Pamela requires a power supply box (to be bought separately) to work.

MADE IN ITALY

DIMENSIONS

Ø 50 x 182 h cm - Inch Ø 19.7 x 71.6 h



**FINISHES** 



Satin Light Brass



#### **PAMELA**

#### TECHNICAL INFORMATION

Base and Stem

Black painted steel base with anodized alluminium sheet and stem on top.

Lamp shade

Steel frame and fabric, paired with plastic material or laser-cut multilayer sheet, varnished.

Finishing and painting cycle

Wood treated with solvent or water dye, polyurethane base; solvent shading, matt polyurethane. Metal treated with transparent nitre solvent.

Lighting system LED.

Power supply box

Input:  $100-240V \sim 0.7A$ , 50-60HZ

For indoor use only.

### Maintenance and disposal

Product designed for indoor use. Make sure that the surface does not stay in contact with water or other liquids, even for short periods. The product is made with finishes subject to deterioration if treated with unsuitable substances. Always use neutral and creamy cleaning solutions without alcohol or acids. Never use steel wool or abrasive sponges but a soft wet cloth. Dry thoroughly after each cleaning. The replacement of damaged parts must be done only with original pieces: in this case, please contact an official Armani/Casa dealer for assistance. At the end of its useful life, the product must be returned to an authorized collection center for disposal.