

Juno Fix - Mix - Mix Deep Round & Square

DOXIS
LIGHTING FACTORY

Instructions:

1. Drill a hole in the ceiling
2. Connect LED to driver
3. Connect 230V to driver
4. Insert driver and spot into ceiling

Forward voltages and nominal drive currents are mentioned on the label supplied with the product or can be found in the technical datasheet of the product.

Always use the correct driver.


Always install the driver according to the wiring schematics supplied with the driver.

Always check if multi-current drivers are set to the correct output current.

Doxis Lighting Factory cannot be held responsible for damage caused by using the wrong driver.




Juno Fix: Ø43mm
Juno Mix: Ø54mm
Juno Mix Deep: Ø54mm




1

Connect LED
Red wire: +
Black wire: -




2

Connect 230V



3



Push in sides

4

⚠ Attention!!

Always follow the instructions described in this document and store this document for future reference.

Do not touch LED surface. Warranty void if LED contact has taken place.
Only to be installed by a qualified electrician.


Always make sure power is completely switched off when working on luminaire.

Doxis Lighting Factory NV cannot be held responsible for any damage caused by incorrect installation, modification, reparation or incorrect application/usage of the product.

Juno Fix

Air circulation notice:

Do not topload with insulation materials



Juno Mix & Mix Deep

Air circulation notice:

Do not topload with insulation materials

